

PROZONE WATER PRODUCTS, INC.

Ozone Water Purification Systems

Assembly and Installation of Noise Attenuator Kit M09 on Ozonator Models PZ2-1 and PZ2-2

INSTRUCTIONS:

1. Check M09 Kit for completeness.
2. Screw the 1/2" MPT x 3/8" HB fitting into the 1" SP x 1/2" FPT fitting.
3. Insert this assembly into the 1" coupler.
4. Press one end of the 3/8" Hose onto the 1/2" MPT x 3/8 HB fitting.
5. Slide this assembly onto the 1" fitting on the PZ2-1 or PZ2-2 Ozonator.

Note: It is not necessary to glue the parts together.

CAUTION: Locate the hose so that debris, dust, oil, chemicals, or other objects cannot be sucked into the system.

INSTALLATION KIT INVENTORY

Description	Part Number	Quantity
Polybraid Hose 3/8"	20261	24"
PVC Fitting 1"SP x 1/2" FPT	20534	1
PVC Fitting 1" Coupler	20487	1
Kynar Fitting 1/2" MPT x 3/8" HB	20231	1
Wire Tie	20134	1